



# Z-3 TIR

## GRILLE / SURFACE MOUNT

### Flash Pattern List

- Long Slow Single
- Long Single
- Long Fast Single
- Triple
- Slow Single
- Single
- Fast Single
- Fastest Single
- Single/Burst Combo
- Quad
- Fast Quad
- Slow Triple
- Quad Burst
- Fast Quad Burst
- Short Single
- Short Fast Single
- Slow Single/Burst Combo
- Fast Accelerating
- Accelerating
- Slow Accelerating
- Fastest Accelerating
- Strobe

### Alternate Sync Flash Pattern List

- Slow Alternating
- Medium Alternating
- Fast Alternating

### Flash Pattern Shortcuts

- Hold for 2 seconds to toggle Steady Burn mode.
- Hold for 4 seconds to toggle Auto cycle through mode.